



Metal Finishing Systems

Birchwood Laboratories, Inc.
7900 Fuller Road
Eden Prairie, MN 55344 USA
Tel: 952/937-7931
Fax: 952/937-7979

www.birchwoodcasey.com

ALUMA BLACK® A15 Blackening Solution

Operating Instructions

PRODUCT DESCRIPTION

ALUMA BLACK® A15 Blackening Solution works on all forms of aluminum to form a non-dimensional black finish. Supplied as a liquid concentrate, the product is diluted with water and applied by immersion techniques. The finish can be sealed and used as a solid black finish on machine components, or highlighted to produce a simulated pewter finish on decorative hardware.

OPERATING CONDITIONS

Bath Makeup	33% by volume. (2 parts water + 1 part A15)
Equipment Construction	Plastic, or acid proof materials.
Ventilation	Desirable.

BLACKENING PROCEDURES

1. CLEAN & DEOXIDIZE the metal surface to remove all oils and oxide films. (All aluminum carries a transparent, natural oxide that must be removed prior to blackening) Acceptable methods of cleaning include bead blasting or chemical cleaning in SAFE SCRUB® M Multi-Metal Cleaner, mixed at 20% by volume; 150° F; 5-8 minute immersion.
2. RINSE parts in clean water; 20 seconds.
3. BLACKEN by immersing parts in ALUMA BLACK solution until parts are uniformly gray/black in color.
4. RINSE in clean water; 20 seconds.
5. SEAL the black finish with SATIN SHIELD® SS10 acrylic sealant, or in CLEARLOK® urethane emulsion. Allow to dry.
OR, dry the part, highlight with an abrasive pad to produce an antique finish, and lacquer.

BATH MAINTENANCE

As the ALUMA BLACK bath operates, its concentration will gradually diminish. The bath should be replenished with A15 concentrate to restore normal strength, based on testing with the CCK test kit, available from BIRCHWOOD CASEY.

PACKAGING & STORAGE

1 and 5 gallon plastic containers; 55 gallon plastic, non-returnable drums. Store indoors in closed container.

Before Using This Product – Please Read, Understand and Follow all the Precautions shown on the Product Label and on the Material Safety Data Sheet.

The Material Safety Data Sheet can be found on our website: www.birchwoodcasey.com

Always Apply Appropriate Labels to any Container used to Store or Apply this Product.

NOTE: The information contained herein is provided in good faith and is believed to be correct as of the date hereof. However, Birchwood Laboratories, Inc. makes no representation as to the comprehensiveness or accuracy of the information. It is expected that individuals receiving the information will exercise their independent judgment in determining its appropriateness for a particular purpose. Accordingly, Birchwood Laboratories, Inc. will not be responsible for damages of any kind resulting from the use of or reliance upon such information.

ALUMA BLACK® A15 (Product Numbers: 620050, 620051, 620058)

©Birchwood Laboratories, Inc.

May 2007